


Precaution



Precaution

[illegible]

A Quality Product
Of
CG
Securing life extension

USER MANUAL




CG-HP3201

CG CHAUDHARY®
GROUP
Touching life everyday

How to use

Before using your dispenser for the first time, boil and discard one full pot of water by following the instructions below. You may notice a smell of plastic for the first time when you use the dispenser. This is normal and will fade over time.



How to use

To dispense water
By Manual pumping




By pushing cup
against spout switch

By pressing
the dispense button
on the control panel

How to use

Re-boil key When the dispenser is in keep-warm mode, use this key to re-boil the water.



Parts N a m e s

