



INSTRUCTION MANUAL

Read this manual carefully before operation

Pictures in this manual are for reference only, the product in kind prevail.



Model: CGID1001SB, CGID1001SH

This instruction manual contains important information & recommendations that we would ask you to comply with to obtain best results form your products.



1. If clothes of different types of fabric are to be ironed, the clothing which requires least temperature should be ironed first i.e. Selection of temperature range should be from lower to higher. Nylon requires lowest temperature and linen, the highest.

NOTE:

WHEN CHANGING THE KNOB FROM HIGH TO LOW, SETTING, ALLOW FEW MINUTES FOR THE IRON TO ADJUST ITSELF TO THE NEW TEMPERATURE.

MAINTENANCE:

- 1. Use mild detergent/ soap solution with a soft cloth to remove deposits of starch / finishes from the sole plate of your iron.
- 2. In no case, the iron should be immersed in water.
- 3. The handle should be wiped over with a soft damp cloth.
- 4. In case of insulation sleeve is provided over the insulation of supply cord. Insulation to the effect that while replacing the supply cord & insulation sleeve made of finerglass of equivalent material should be used over the cable insulation.

USEFUL HINTS:

- Avoid standing or placing iron on hard or gritty surface. otherwise it may get scratched.
- During breaks in actual ironing process and when it is being cooled, keep the iron in upright position.
- 3. Never wrap cord on iron handle.

OPERATION MANUAL

Carefully read this manual before using this iron. A few minutes spent in this will ensure proper and satisfactory performance of this product. Read these instruction and retain for future use.

When switching on this iron for the first time. fumes may be emitted, but it shouldnot be cause of worry. These fumes. are produced by the protective lubricants and preserving agents getting burnt off. This is not a fault and fumes would quickly disappear.

VOLTAGE SUPPLY

Please ensure that your supply voltage matches with that on specifications plate on the iron.

SAFETY:

- Please ensure that the green wire is connected to the earth terminal.
- 2. After use remove the plug and allow the iron to cool.
- 3. Before attempting any cleaning, ensure that the iron is disconnected from the mains supply and has cooled down.
- 4. Do not leave the iron unattended in working conditions.
- 5. Allow iron to cool in upright position only.

HEAT SELECTION

Should be set against indicating arrow to suit the type of fabric/cloth that you like to iron. This ensures that the required temperature in maintained and any risk of overheating eliminated.

WARRANTY CERTIFICATE

This iron is warranted against any manufacturing defect or workmanship for one year from the date of purchase and would be replaced / repaired free of cost.

If this product does not perform properly, return it to the nearest authorized dealer transportion charges prepaid

Damages resulting from accidents mishandling or negligence on the part of customer, repair by unauthorized personnel/ dealer and abnormal variation in supply voltage does not apply for warranty. Glass parts, bakelite part lamp, cord and plating/coating are not covered by warranty.

TEST CERTIFICATE

Batch#	Visual Inspection	
	General Finish	OK
Name & Address of Customer	SAFETY TEST	OK
	HV Test	OK
Name & Address of Dealer with Stamp	Leakage Current	OK
	Earthing Connection	OK
111111111111111111111111111111111111111	Input Watts	OK
	Performance Test	
	Sole Plate Temp.	OK
Cash Memo No. & Date	Tested By :	
Signature of Dealer		

A Quality Product







IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCEWITH EC DIRECTIVE 2002/96/EC.

At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossedoutwheeled dusthin.

Visit us at; www.cginspiringlife.com