

Halogen Heater INSTRUCTION MANUAL

Read this manual carefully before operation

Pictures in this manual are for reference only, the product in kind prevail.



Model: CGQH22B

This instruction manual contains important information
& recommendations that we would ask you to comply
With to obtain best results from your products.


Dear Customer,

We thank you very much for having purchased one product of ours. We kindly ask you to read and save this instruction manual.

IMPORTANT SAFETY PRECAUTIONS

- The heater work under 220-240V AC, make sure to insert the plug into the suitable electrical outlet but do not keep it plugged in when not use.
- The heater must not be located immediately below a socket-outlet.
- Do not use this heater in the immediately surroundings of a bath, a shower or swimming pool.
- Do not use the unit in the occasion of flammable or easy explode object around.
- Do not cover the appliance when it works.
- Do not leave the appliance unattended while switched on, especially when it is used near children or animals
- Do not operate the heater with a damaged mains lead or plug, or after the heater malfunctions, or is dropped or damaged in any manner. Never disassemble it by yourself. Please send it to the manufacturer or its service agent or a similarly qualified person for repair.
- When the unit is not in use, please pull out the plug from the socket.
- CAUTION: In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

ASSEMBLE ILLUSTRATION



BRIEF INTRODUCTION

- The item applies infrared heating technique, which can be easily absorbed by human bodies. Even though it

- is used in a poor air proof or spacious room, it can provide ideal warming effect.
- The heater bears novel design, elegant outlook and the following features as well:
 - Adopting quartz tube, heated thread, which can heat up quickly along with the heat change efficiently.
 - New design, which can provide high quantity of heat reflecting.
 - Fall over switch, which can cut off the power to ensure safety when it fell down.

TECHNICAL DATA

Model No	Spec.	Voltage/Frequency	Package(mm)	Power	N.W/G.W
CGQH22B	4Tubes	220-240V~50-60Hz	530x180x560	2200W	4.6/5.5KG

OPERATION

- Plug into socket. Turn on the rotary switch will start heating up from up to down.
- The first speed position is 550W(1 pc rod working)
- The second speed position is 1100W(2pcs rods working)
- The third speed position is 2200W(4pcs rods working)
- When not use, turn off all power switches and unplug the appliance.

CLEANING AND MAINTENANCE

- Clean the reflector on regular basis in order to avoid fire hazard due to dust and dirty accumulation.
- Before cleaning, the plug must be removed from the socket-outlet.
- Take down the front steel grill.
- At first use a damp cloth to wipe off the dirt from reflector surface, and then clean again with a wet cloth, finally clean it again with a damp cloth. Dry the reflector surface with soft, dry cloth.
- After cleaning, fit the front steel grill back on.
- The unit surface can be cleaned with wet cloth. Furthermore, it can be cleaned with suds or some detergents. Do not use gas or chemical agents.

WARNING

- Do not locate the heater below a socket outlet.
- Heater may not use program, controller, timers or other device to automatically connect heater.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- This heater not installed temperature control device which used to the room. When those who have no ability to left his little room, who shall not take up using the heater in these small rooms, unless the person who have ability to continue to provide care
- Children aged from 3 years and less than 8 years shall not plug in, regulate
- and clean the appliance or perform user maintenance.

CAUTION: Some parts of this product can become very hot and cause burns.
Particular attention has to be given where children and vulnerable people are present.

**A Quality Product
Of**

**CG CHAUDHARY®
GROUP**
Touching life everyday



**IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT
IN ACCORDANCE WITH EC DIRECTIVE 2002/96/EC.**

At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.